

## Conversion times VB-FullAir kits

(for reference only)

Brand	Type	Time in hours
<b>Citroën</b>	Jumper / Relay	6-8
<b>Fiat</b>	Ducato	6-8
<b>Ford</b>	Transit 260 - 330 FWD	6-8
	Transit 260 - 330 RWD	6-8
	Transit 350 - 430 RWD Twin-wheel	8-10
<b>Isuzu</b>	NQR	10-12
<b>Iveco</b>	Daily 35C - 40C	6-8
	Daily 45C - 50C	6-8
	Daily 60C - 65C	8-10
<b>Mercedes-Benz</b>	Vito / Viano	5-7
	Sprinter 208 – 316	8-10
	Sprinter 408 – 416	8-10
	Sprinter 616	8-10
	New Sprinter 209 – 318	6-8
	New Sprinter 409 – 518	6-8
<b>Nissan</b>	Primastar	5-7
	Interstar	6-8
<b>Opel</b>	Vivaro	5-7
	Movano	6-8
<b>Peugeot</b>	Boxer	6-8
<b>Renault</b>	Kangoo 4x4	5-7
	Espace	5-7
	Trafic	5-7
	Master	6-8
	Mascott/ Master Pro / Master Maxi	8-10
<b>Volkswagen</b>	T4	6-8
	T5	5-7
	LT	8-10
	Crafter 28 – 35	6-8
	Crafter 35 – 50	6-8

The technical specifications are the standard VB-Airsuspension versions. Other specifications are on request.

VB-Airsuspension reserves the right to make changes without prior notification.

03-2006